

FORTE INOX



Description:

Essential detergent to clean and degrease ovens, cookers, along with floors and tiles. Dissolves food-based stains such as proteins, fat, cooking deposits and burnt residues. With its special inhibiting agent it can also be used on aluminium.

Directions for use:

- Regular cleaning of surfaces: 30 - 90 ml (1-3 caps, 1 dosing cap = 30 ml) in 4 l of water.
- Intense cleaning (surfaces / wet method: manually or with a machine) 120 - 480 ml (4-16 caps, 1 dosing cap = 30 ml) in 8L of water.
- Maintenance treatment: use undiluted, preheat the oven, grill, etc. at 30°C and turn off. Foam up the product on the surface, leave for 5-10 minutes and rinse thoroughly.
- Cleaning after construction work / deep cleaning: 1L in 8L of cold water. Apply the solution on the floor, leave for about 10 minutes, rub, vacuum clean any deposits of dirt, rinse thoroughly with clean water. In case of stubborn dirt, water at 40-60°C accelerates the action of the product. In case of grease or protein deposits, use the product with the specified concentration (cold) and apply hot water via the machine's tank when cleaning the floors.
- Cleaning with a foam sprayer and non-foam sprayers: apply with a dilution ratio from 1:4 to 1:10.

PLEASE NOTE: Cleaned surfaces intended for food preparation must be thoroughly rinsed with water (8 L per m²).

Warnings:

To handle the product follow the precautionary advice on the safety data sheet.

Technical Features:

Appearance and colour: clear liquid

Odour: characteristic

pH: 11.21

Flash point: >100°C

Relative density: 1.13 g/cm³

Solubility in water: soluble

Lipid solubility: partially soluble

Storage:

Unopened and stored at room temperature away from direct sunlight.

Packaging

PACKAGING

1 L BOTTLE + 30 ml dispenser cap (6 pcs)

JERRY CAN 5 Kg

JERRY CAN 25 Kg.

ITEM CODE

77086

77087

77088

FRA-BER s.r.l.
Head of the Laboratory

Original signed document available at the company's headquarters. The data contained is the result of technological research of our laboratory and is provided for information purposes only. We exclude any liability arising from an incorrect choice of product and the lack of the necessary precautions, which must always be verified by the user.